GASOLINE ENGINE TACHOMETER

Model: DT-2237A

ISO-9001, CE, IEC1010







The Art of Measurement

GASOLINE TACHOMETER

Model: DT-2237A

| | SPECIFICATIONS |
|--------------------|--|
| Measured Engine | 4 cycle - 2,3,4,5,6,8,10,12 no matter what |
| | cylinder is. |
| | 2 cycle - 1,2,3,4 no matter what cylinder is. |
| Reading Range | 10 to 40,000 RPM. |
| Resolution | 0.1 RPM (<1,000 RPM), |
| | 1 RPM(≥1,000 RPM). |
| Display | 5 digits, 10 mm (0.4 ") LCD. |
| Accuracy | ± (0.05 % + 1 digit). |
| Sampling Time | Approx. 1 second. |
| Memory | ast value, Max. value, Min. value. |
| Time Base | Quartz crystal. |
| Circuit | Single chip C-MOS micro-computer. |
| Signal Sensor | RPM inductive pick up sensor. |
| Signal Sensing | Secondary Tach. measuring method, no matter |
| Principle | what cylinders is. |
| Housing | Durable ABS plastic. |
| Battery | 4 x 1.5 V AA (UM-3) battery. |
| Power Consumption | Approx. DC 10 mA. |
| Power Failure | Build in low battery indicator. |
| Operating Temp. | 0 to 50 °C (32 to 122 °F). |
| Operating Humidity | Less than 90 % RH. |
| Dimension | Main instrument - |
| | 190 x 72 x 37 mm (7.5 x 2.8 x 1.5 inch). |
| Weight | 250 g/0.55 LB (including battery, w/o sensor). |
| Accessories | RPM inductive pick up sensor 1 PC. |
| Included | Carrying case 1 PC. |
| | Instruction manual 1 PC. |

MEASURING PROCEDURES

- 1) Select engine type (4 or 2 CYCLE engine) from CYCLE selector.
- 2) Insert the PLUG into the SOCKET.
- 3) Connect the RPM INDUCTIVE PICK UP SENSOR to the HIGH TENSION WIRE of No. 1 SPARK PLUG (or No. 2, No. 3... SPARK PLUG).
- 4) Push the MEASURING BUTTON, verify that the "Monitor Indicator " lights when the signal input. Then the display will show RPM reading and update every second.

^{*} Appearance and specifications listed in this brochure are subject to change without notice. 1301-DT2237A